


## Screen Views



### Work Screen

Shows the the most important settings, once the unit is configured. Displayed automatically after 45 sec of inactivity.




### Sub-menu Screen

Select feature by scrolling.



Swipe left or right to change value between the arrows

## Screen Lock



To activate the touch screen lock, press the Menu button, select the Setting wheel and go to Touch and select on / off



## Connection



The ONE should only be used between -10°C and 40°C. Only charge the ONE between 0°C and 40°C.

USB-C socket for charge and firmware update.

Hard reset hole.

### USB-C Charger

Use only the original Elinchrom One USB Charger to recharge the built-in Li-Ion battery.

When the unit is OFF the side logo color shows the charge status:  
Red: recharging  
Orange: almost charged  
Green: the unit is charged

Recharging time: 100 min. to 100%

Battery capacity min./max power: 9700 / 725 flashes per charged battery.

### Reset To Default Settings

Switch the unit on, and release the ON button. When the EL Logo appears press immediately the "ON" and "Menu" button for 4 seconds until the display shows "Reload all default parameters".



[www.elinchrom.com](http://www.elinchrom.com)



Elinchrom is a registered trademark of ELINCHROM LTD, RENENS, SWITZERLAND

QSG ONE - 10.2022

Av. de Longemalle 11, CH-1020 Renens, Switzerland,  
Tel.: + 41 21 637 26 77 Fax: +41 21 637 26 81 E-mail: [support@elinchrom.ch](mailto:support@elinchrom.ch)

 elinchrom®

# ONE



## Quick Start Guide

## Setup Menu

**Action mode** Switch on/off

**Settings** Submenu access

**Sound** Switch on/off

**Photocell** Switch on/off

<b>Settings</b>	Flash before ready	Yes/No
	Flash scale	EL-Scale, 5.8 – 10 (10 scale), Ws
	Modlamp VFC	Off/On
	Modlamp Timer	Off/15*/30*/60"
	Modlamp Scale	F-stop/Percent
	Favorite function	Modlamp/Flash mode/Audio/Photocell/Recycling mode
	Auto stand-by	Off, 1 to 59 min. Auto-off and auto stand-by shall be set independently. Auto stand-by cannot disable auto off.
	Auto-off	Off, (Auto stand-by+1) to 60 min. It shall be longer than Auto stand-by. Minimum value = auto stand-by + 1min.
	EL logo mode	Low, High, Off, Low on ready, High on ready
	EL logo color	Group color, White
	Ready tone	1, 2, 3
	Ready volume	Off, Low, Medium, High
	Keyboard click	Off/On
	Skyport	Off/On
	Touch	Off/On
Wireless update	Setup wifi SSID and password	

To access the menu short tap on screen with 2 fingers

**G4 Groups** Swipe to choose the Group

**Presets** Select, the color temperature

**F20 Frequencies** Swipe to choose the frequency

**Background** Switch to black or white

**Info**

**Bluetooth** Switch on/off

<b>Info</b>	Friendly name	Elinchrom ONE standard, can be changed with the computer or smartphone app.
	Firmware rev.	*****
	Skyport ID	*****
	Life time	In hours (hhh:mm)
	Power-on count	How many times the units has been turned on
	Flash count	Total flash number

## Control panel / Touch Screen

**Photocell**

**Menu**

**Long press:** on/off  
**Short press:** switch display to Lock on / Flash / Modelling Lamp / LED colour temperature

**Save button:** press for validate your choice

↻ CW: +0.1 f-stop / down

↻ CCW: -0.1 f-stop / up

## Display panel – Dashboard

The colour of the Group corresponds to the group number : blue for group 1, yellow for group 2, red for group 3 and green for group 4. The Elinchrom logo on the side of the unit illuminates with the color of the selected group.



- Group 1-4
- Modelling lamp menu
- Battery status
- Favorite Function; default setting is Mod. Lamp on/off
- Power value

## Modelling lamp

Swipe down to access the modelling lamp menu

Short touch to access and change the colour temperature

Swipe left/right to change values